

Warranty Claim

Please contact your supplier with your original purchase invoice and unique chair batch number and they will make the necessary arrangements with Repose.

If you are in any doubt about any information or instructions please contact your local supplier for further assistance.

Batch Number

Recommended supplier

Contact Us

Attwood House, Cokeland Place, Cradley Heath B64 6AN

Tel: 0844 7766001 Fax: 0844 7766002

Email: info@reposefurniture.co.uk

Web: www.reposefurniture.co.uk



Thank you for supporting British manufacturers

Repose Furniture Ltd reserves the right to modify or change the specification without prior notification. For terms and conditions of sale and or agreement please refer to your supplier.



www.reposefurniture.co.uk



Stargazer User Instructions



REPOSE FURNITURE LTD

www.reposefurniture.co.uk




Dr Hilary Jones
Our In-house Health Advisor

“The Stargazer provides compact comfort, extending care to family members staying through the night to be near their loved ones.”

Your chair

Getting Started

- Safety instructions
- Chair Set up
- Upholstery care
- Warranty

Warranty

Your Repose chair comes with a 2 year warranty on the mechanics and metal frame. You also have a 1 year warranty on the wooden frame, upholstery and alternating seat cushions.

Repose will repair or replace, at our discretion and free of charge to the original purchaser, any parts covered by this warranty and that on examination, are found to be defective in material and/or workmanship. The warranty is for parts and labour only and for transportation to and from the original delivery point. It does not include any white glove delivery service. If this is required it will incur an additional cost.

Warranty Exclusions

- Fabric damage resulting from misuse, negligence, abuse, accident or incorrect cleaning
- Unauthorised repairs, alterations and modifications
- Damage to the chair from misuse, negligence, abuse or accident
- Damage caused by common carrier abuse or mishandling and any special, indirect, incidental and/or consequential damages.

Other fabrics (Panvelle, Highland, Aston)

There are many other fabrics available on this model, where special cleaning instruction will apply. If your fabric is not one of the following detailed, please ask your supplier for the special cleaning instructions. Failure to clean by the recommended guideline could result in damage to the fabric.



- Vacuum and wipe clean regularly with a damp cloth (microfiber recommended) and water to remove dust particles and prevent build-up of soiling.
- Take care not to cause abrasive damage.
- Remove spillages promptly with an absorbent dry cloth.
- For heavier soiling, use a mild proprietary cleaner and warm water ensuring that cleaning product residues are removed as this inhibits the stain repellent
- For infection control purposes, staining should be removed promptly (within 15minutes) with COLD water and then cleaned as above. A 5% bleach solution, Haz Tabs or Chlor Clean may be used.
- Water and oil based stains may be removed by using most water based house proprietary spray cleaning agents, following the instructions carefully and removing all soap residues.
- Do not apply other chemicals

Thank you

Repose Specialist Seating Solutions

Stargazer Sleeper

The Stargazer is an innovative solution to the problem of short term bed provision, whether this is for a visitor at a patient's bedside, for staff to take a break, or to provide comfortable rest for people facing long delays. The Stargazer is designed with the same commitment to comfort we demonstrate in all our chairs, with deeper foam cushions than any other ready bed available to ensure real rest and recuperation.

Design Features:

- Compact and modern design that will complement any environment
- Simple two step movement to quickly transform the chair into a bed
- Fully washable, bleach cleanable, anti-MRSA vinyl upholstery
- Available in a range of colours to suit your interiors
- Built in castors for ease of movement for cleaning purposes.

Comfort Features:

- Deep Parlex foam cushioning to give the ultimate comfort when sitting for long periods of sleeping
- Easy pull mechanism to release the two bottom sections of the back, with the headrest tilting to form the third section and provide a full length bed for users.

Chair Sizes

• Seat Hight: 18" (40 cm)	• Seat Width: 21" (50 cm)
• Seat Depth: 21" (50cm)	• Bed Length: 61" (155cm)
• Overall Width: 35" (89 cm)	• Overall Depth: 34" (86 cm)
• Overall Hight: 24" (61 cm) (from floor to arm height)	• Overall Hight: 34" (86 cm) (from floor to top of back)

Please note the Stargazer Sleeper is not intended for patient use.

Appropriate for: Waiting and Rest Areas, Healthcare, Nursing and Residential Homes

COMFORT WITHOUT COMPROMISE
www.reposefurniture.co.uk Tel: 0844 7760001

Thank you for purchasing a Repose Stargazer chair. Please take time to read this leaflet which contains essential instructions on your chair set up, handset usage and upholstery care, as well as important safety, warranty and contact details. However, if for any reason you are unsure of anything, please contact your supplier immediately for further information.

Important Safety Instructions

The following instructions are for your own safety, the safety of others and to ensure that the chair is used correctly and in line with the warranty conditions.

Please note that the stargazer sleeper is not meant for patient use.

PLEASE ENSURE THAT YOU KEEP THESE INSTRUCTIONS SAFE as you will need them for reference purposes.

- **ALL CARERS AND ATTENDANTS** who are responsible for setting up the Stargazer should understand and follow the set up instructions. **Please take care** to ensure that you do not trap your fingers in any of the moving parts.
- **YOU UNDERSTAND** the recommended user weight limit for the Stargazer and ensure that you **DO NOT** exceed it. To do so may cause damage to the Stargazer and will invalidate your warranty. (25 stone)
- **YOU ALWAYS** use the locking castors when the Stargazer is stationary.
- **YOU CHECK** the Stargazer regularly to ensure that it is in a suitable working condition and that there is no damage. **DO NOT** use the Stargazer if it is not working properly or damaged.
- **YOU ALWAYS** use the both arms of the chair to move Stargazer around and **ALWAYS** stand in front of the chair when moving.
- **NO ONE** is sitting in the Stargazer when it is being moved.

Under no circumstances should the Stargazer be stood on when the headrest section has been converted into the bed position. This is design for a temporary bed solution.

Cleaning instructions for Boltaflex cadet

Pamaz Healthcare T | 01282 696969
E | Marketing@pamaz.co.uk
W | www.pamaz.co.uk

Cadet™ Contemporary 2
performance vinyl

Now durable to 350,000+ Martindale Rubs

Featuring a new design – "Etch" – available in 9 enticing colours

- Flame retardant to Crib 5
- Waterproof
- Stain resistant
- Cleanable with bleach
- Durable to 350,000 plus Martindale rubs
- Anti-Microbial with Shield Plus
- Phthalate Free

shieldplus technology

This unique antimicrobial is exclusive to Panaz fabrics and affords Cadet Contemporary 2 protection unlike any other fabric in the market

Unlike silver and other inorganic anti-microbial agents, Shield Plus™ is:

- Non-leaching and non-migrating technology that is encapsulated permanently within the vinyl
- Destroys bacteria on contact and with immediate effect
- Endures and is active for the life of the fabric
- Does not deplete
- Does not create immunity to the agent or adaptive organisms
- Targets the broadest spectrum of microbes – effective even against the C diff spore
- Is safe for the environment and you – free from toxic metals
- Has worldwide registration

<p>Call response</p> <p>Attraction</p>	<p>Upon contact</p> <p>Perforation/Electrocution</p>	<p>Safe and optimal</p> <p>antimicrobial protection is provided even after frequent cleaning</p>
--	--	--

This mechanical action ensures that bacteria, fungi and algae are effectively and immediately controlled.

For further information please visit:
www.pamaz.com

Cleaning Recommended:

- The new generation of microfiber cleaning cloths are extremely effective without soap for general care and maintenance
- Wipe clean regular with a damp cloth to remove dust and light soiling.
- Remove spillages promptly (within 15 minutes) with an absorbent dry cloth
- For general soiling, use a soft brush with care to avoid abrasive damage to surface and tepid soapy water (non alkaline). Rinse clean with clear water. Dry with an absorbent cloth.
- Body fluids should be removed promptly (within 15minutes) with cold water and then cleaned as above. Extreme soiling/ infection control use 5% sodium hypochlorite (bleach) solution.

Upholstery Care

- **ALWAYS** ensure that you follow the cleaning instructions for **YOUR PARTICULAR UPHOLSTERY**. Your supplier will provide you with cleaning instructions. Please note that different fabrics will have different characteristics and cleaning instructions. **ASK YOUR SUPPLIER IF YOU ARE IN ANY DOUBT** about the cleaning instructions. Repose cannot be held responsible for any damage caused by cleaning.
- Regular cleaning is required to maintain the appearance and cleanliness of your Stargazer. Small dust and dirt particles can increase the wear and tear of the upholstery and may dull the fabric.
- Your fabric should not be exposed to direct sunlight for long periods of time as this will cause your fabric to fade. If your furniture is positioned within prolonged light, ensure your curtains and blinds are drawn for protection.
- Ensure the upholstery is protected from sharp objects or buckles as these may cause the upholstery to snag or become damaged.
- Avoid allowing pets onto the Stargazer as their claws may cause damage to the upholstery. All animals have a degree of oil in their coats which may transfer to your fabric if they go onto the chair. This will cause your fabric to prematurely wear.

- Children **DO NOT** play on, or with, the Stargazer. To do so may result in personal injury.
- **NO ONE** stands or sits on the arms or back rest as this may cause the Stargazer to tip and/or damage the Stargazer. To do so may result in personal injury.
- **NO ONE** stands on the seat or bed as this may cause the Stargazer to tip and/or damage the Stargazer. To do so may result in personal injury.
- **YOU ONLY USE** approved parts on your Stargazer. These can be obtained through your supplier. Failure to use approved parts will invalidate your warranty.
- **YOU ALWAYS** get your supplier to carry out any repairs or fit new parts to the Stargazer. **DO NOT** attempt to carry out your own repairs to the chair as this will invalidate the warranty.
- **YOU PROVIDE** your original purchase invoice and unique Stargazer batch number when ordering parts or when making a claim under your warranty.

Under no circumstances should the Stargazer be stood on when the headrest section has been converted into the bed position. This is design for a temporary bed solution.

Chair Set Up

The versatile Stargazer has 3 relaxing positions that deliver additional comfort to any environment:

Position 1 – A comfortable chair



Position 2 – An extended chair for those who wish to stretch out their legs



Position 3 – The full bed for long periods of sleep or rest



Chair Location

Position the Stargazer in your chosen location, ensuring that there is enough space for the base to be fully extended to form the bed. You will find the dimensions of the Stargazer on the product leaflet. The dimensions are as follows:

- Seat Depth - 21" (53 cms)
- Seat Width - 27" (69 cms)
- Seat Height - 16" (41 cms)
- Bed Length - 81" (206 cms)
- Arm Height - 24" (61 cms from floor to top of arm)
- Overall Height - 34" (86 cms from floor to top of back)
- Overall Width - 35" (89 cms)
- Overall Depth - 34" (86 cms)

Simply push the top of the back cushion down and push into the space. Once the cushion is in place, with a slight rise to act as a pillow, the bed is ready.

There are two small finger pulls on either side of the back cushion to enable you to pull the back upright into position.



To convert back to a chair reverse the actions detailed above.



1) An Extended Chair

The lockable castors should be in the lock position before commencing these set up instructions.

(Step 1) Pull the fabric handle at the front of the chair just above the front border.



The base unit that the handle is attached to will come out from the underneath of the chair to form a two tiered effect



Important note: If you continue to pull on the handle the seat will also come out. This is not required for the extended chair (this is for the full bed below).

Then put your hands at either side of the cushion on this lower tier extension and pull it upwards and towards you

(Step 2) The seating on this base works on a mechanism that allows the base to rise and move into a position where it will rest safely on the front of the skirting to form an extended seat.



1) A Full Bed

The lockable castors should be in the lock position before commencing these set up instructions.

Pull the fabric handle at the front of the chair just above the skirting. This will extend the base of the chair as the base unit comes out from underneath of the chair **(Step 1)**



Continue to pull the handle and the seat of the chair will also extend to form a two tier effect.

Then put your hands at either side of the cushion on this lower tier extension and pull it upwards and towards you **(Step 2)**.



The seating on this base works on a mechanism that allows the base to rise and move into a position where it will rest safely on the front of the skirting to form an extended seat.



You will be left with a gap at the back of the bed. This is where the back cushion, when re-positioned, will fits.